

PERRIN

Intercooler Support Bracket for 2002-07 WRX/STI

2026-04-09

PSP-ITR-401

Thank you for purchasing this PERRIN product for your car! Installation of this product should only be performed by persons experienced with installation of aftermarket performance parts and proper operation of high performance vehicles. If vehicle needs to be raised off the ground for installation, the installer must use proper jacks, jack-stands and/or a professional vehicle hoist for safety of the installer and to protect property. If the vehicle is lifted improperly, serious injury or death may occur! Please read through all instructions before performing any portion of installation. If you have any questions, please contact our tech department prior to starting installation. We can be reached in any of the following methods:

Email Tech@PERRIN.com

Instant Chat off the main page of www.PERRIN.com

Or simply call our tech team at 503-693-1702



WARNING: This product can expose you to chemicals including Lead which is known to the State of California to cause cancer birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov

Special Notes:

- If installing with a non-PERRIN Intercooler, take note of the 2 sets of holes used to mount the bracket. Normally we suggest to mount the beam lower for 2002-2003 & 2006-2007 cars, and high 2004-2005 cars need the beam mounted higher. This may vary depending on aftermarket parts installed.

Parts Included with the PERRIN Front Mount Intercooler:

QTY	Part Number	Part Description
1	X-PSP-ITR-401BK	Intercooler Support Bracket for 2002-07 WRX/STI Black

Installation of PERRIN Front Mounted Intercooler

1. Follow instructions for your specific PERRIN Front Mounted Intercooler until you get to the point of installing the Intercooler to the intercooler support bracket.
2. Place bumper beam between tabs on intercooler core. This can be a tight fit and may require some force to get the beam seated. **NOTE: A dead blow hammer can be used on the corners of the beam or brackets to get the bumper beam to fit. Do not hit the center of the beam as it can easily dent.**
3. Once bumper beam is in place, install supplied 3/8" bolts and washers through holes in intercooler tabs and through bumper beam. Then install supplied washers, lock washers, and nuts to secure. Then skip to Step 4. **NOTE: You may need to slide bumper beam around to get holes to line up, using a dead blow hammer to tap it left or right can help. Also, a screwdriver or punch tool place through the holes can be used to pry the intercooler into place.**



4. With intercooler mounted and aligned properly, tighten 3/8" bolts to 15ft-lbs.
5. Continue with installing the rest of your PERRIN Front Mounted Intercooler Kit using the instructions for your specific model year. NOTE: T

Questions, Comments and Suggestions Contact: Tech@PERRIN.com

Visit Our Website for Instant Chat Options at www.PERRIN.com

Call Our Tech Team at 503-693-1702